Fuel Injection Monitor System (FIMS) MK III

Designed by C.J.Brady © Conehead Ltd 2012

Main Index

Main Index	2
Figure Index	3
Introduction	4
Cables	5
Diagnostics Connection cable between the analog interface and the 14CUX serial port	5
Analog interface to processor unit cable	
Breakout cable for the injection loom	7
FIMS Analog Interface Unit	8
FIMS Processor Unit	10
Processor Unit – Front Panel LED Wiring	11
Processor Unit – LCD Wiring	12
Processor Unit – Schematic	13
Processor PCB Conn5	13
Processor unit DB15 Chassis Mounted Male Plug	14
Appendix A – D Connector Pin Numbering	16
Appendix B – TTS Plug Wiring	17

Figure Index

Figure 1 – Layout of the analog and processor/display units – which together make up FIMS	4
Figure 2 – Serial link cable wiring	
Figure 3 – Cable wiring between the analog unit and the processor	
Figure 4 – ECU loom break out cable wiring	
Figure 5 – Analog interface unit - Straight through connections and power (schematic 1 of 2)	
Figure 6 – Analog interface unit - High impedence buffers and darlington driver (schematic 2 of 2)	
Figure 7 – Front Panel LED wiring in the processor unit	
Figure 8 – Front Panel LCD wiring in the processor unit	12
Figure 9 – Processor unit PCB Conn5 (Microchip programming 6 pin RJ11 cable)	13
Figure 10 - Cable layout of 6 pin RJ11 plug (in standard Microchip cable AC162069)	13
Figure 11 – Processor unit rear chassis mounted 15 way male D type	
Figure 12 – FIMS Processor logic schematic	
Figure 13 – D-Type Connector Wiring Pin Numbering	16
Figure 14 – TTS wiring for a diagnostic unit	

Introduction

The fuel injection monitor system (FIMS) is designed to be fitted next to the dash board of a vehicle running the combination of a Rover V8 and 14CUX (Hot Wire) fuel injection system. FIMS allows the driver to dynamically view the state of the lambda signals while also viewing a range of live data read from the 14CUX ECU. It generates a new road speed signal for the 14CUX to suit the non standard combination of fuel injection and Land Rover Series III gearbox and drive train. FIMS requires four sets of connection to the vehicle loom. One to pick up power, one to deal with road speed sensing (in and out), one to connect to the 14CUX diagnostics serial port, and one to collect raw data from the two lambda probes. The system is split into two units. The analog unit is a small black box with three connectors and a power light fitted close to the 14CUX ECU. The processor unit contains a touch screen 2.4" colour LCD and the processor logic and is fitted to the left of the dash board.



Figure 1 – Layout of the analog and processor/display units – which together make up FIMS

Cables

There are three cables used on this system described as follows:-

Diagnostics Connection cable between the analog interface and the 14CUX serial port

Description:

The 14CUX extends its serial port via a 5 pin TTS connector...



The loom socket has a plug cap inserted into it – and which essentially grounds the 14CUX serial receive wire (in order to make sure the 14CUX doesn't mistake electrical noise for a communications packet). Unfortunately, 5 pin TTS connectors are extremely hard to obtain. Therefore a hard wiring connection was made directly between the wires entering the TTS connector using soldered joints and heat shrink and a separate 15 way female D type (which is itself plugged into the analog interface unit).

This cable is relatively short (about 12" long) and note that in order to use the connection the earth blanking plug must be removed from the 14CUX TTS connector socket on the loom.

Loom connection on the existing TTS connector	Description
Black wire	Ground
Green/White wire	This signal originates from ECU pin 9 and is the 14CUX serial port transmit wire
Red/White wire	This signal originates from ECU pin 18 and is the 14CUX serial port receive wire
ŀ	existing TTS connector Black wire Green/White wire

Figure 2 – Serial link cable wiring

Analog interface to processor unit cable

Description:

This cable connects the analog interface unit (located in the battery compartment of the vehicle), to the dash mounted processor box.

This cable is roughly 2mtrs long, and consists of four cables wrapped together. One power cable, a pair of separately screened cables (to carry the buffered lambda signals), and a single 8 core screened cable to carry the remaining signals. The three earth screens (two from the lambda cables, and one from the 8 core cable) are commoned to form a ground. D type connectors terminate both ends of the cable with the end terminating near the 14CUX being male, and the end at the dash board being female.

Note that wiring adheres to the normal D type pin numbering conventions (refer to appendix A). Pin number "n'' at one end will connect to pin number "n'' at the other.

15 Way Female Connector	Description
Pin 1 and Pin 2	12V – using heavy 7amp 1mm CSA Power cable in yellow
Pin 13 and pin 14	Screen of the 8 core cable, and the screen of both lambda signal cables.
Pin 15	Lambda left signal
Pin 12	Lambda right signal
Pin 3	14CUX serial port transmit signal
Pin 4	14CUX serial port receive signal
Pin 5	EFi Check light (the signal issued by the 14CUX when a "check engine" fault occurs. Note this is active low.
Pin 6	Engine electric cooling fans on (this signal is +12v when the engine cooling fans are running).
Pin 7	Raw road speed transducer signal – as read from the transducer fitted in line with the speedometer cable
Pin 8	Road speed output signal. This is a 5v signal output from the processor unit and sent to the analog interface unit – which then uses a darlington pair to amplify the 5v signal to swing between 12v and ground. That signal is in turn fed out from the analog unit as an input to the 14CUX system in order to control when the vehicle switches to idle.
Pins 9, 10 and 11	Spare

Figure 3 – Cable wiring between the analog unit and the processor

Breakout cable for the injection loom

Description:

This cable extends a set of signals from the 14CUX ECU loom, and was carefully added to the loom when the 14CUX was originally added to the vehicle. It terminates in a 24 way female D type connector located physically close to the 14CUX main plug. Note that the FIM system does not require all of these signals. Those that are not used by the FIM are shaded in gray.

25 Way Female	Description
Connector	
Pin 1,2 and 3	Ground
Pin 4	Main relay sink drive (ECU pin 12)
Pin 5	Main relay output (ECU pin 2)
Pin 6	Fuel relay sink drive (ECU 19)
Pin 7	Fuel relay output (to fuel pump)
Pin 8	Road Speed Transducer signal output from the FIM box and fed as an input to the 14CUX. Note that this signal is
	generated by the FIM processor unit.
Pin 9	Left injector sink drive signal (ECU 13)
Pin 10	Right injector sink drive signal (ECU11)
Pin 11 & 12	Spare
Pin 13	Raw road speed signal from the transducer fitted in line with the speedometer cable (note that the transducer is a two
	wire unpolarised device, and the other wire connects directly to 12v)
Pin 14	Spare
Pin 15	Ignition switched +12v
Pin 16	Engine cooling fans activation signal (which is +12v when the engine cooling fans are running)
Pin 17	EFi check engine warning signal. This is the ECU signal that normally connects to a lamp on the dash board to drive a
	"check engine" style warning light. Note that this is an active low signal
Pin 18,19 & 20	Spare
Pin 21	Lambda left screen wire (ie: ground)
Pin 22	Direct connection to the Lambda left signal wire (passenger side)
Pin 23	Spare
Pin 24	Direct connection to the Lambda right signal wire (drivers side)
Pin 25	Lambda right screen wire (ie: ground)
	Figure 4 ECU loom break out cable wiring

Figure 4 – ECU loom break out cable wiring

FIMS Analog Interface Unit

The analog interface unit consists of a box with three connectors, a power LED, and a small (and very simple) circuit board. The primary purpose of this unit is to provide three high impedence amplifiers with which to monitor firstly the left and the right lambda O^2 sensor signals, and secondly the raw road speed transducer signal. An additional darlington pair amplifier is used to amplify the 5v road speed signal from the processor to +12v which is then fed out to the 14CUX as the road speed input.



Figure 5 – Analog interface unit - Straight through connections and power (schematic 1 of 2)



Figure 6 – Analog interface unit - High impedence buffers and darlington driver (schematic 2 of 2)

FIMS Processor Unit

The processor unit is designed to be dash mounted. It contains a 2.4" colour LCD with built in touch screen and a set of four front panel LED's. The logic is relatively simple consisting of a crystal oscillator module, a single quad two input nand gate (74LS00) and a PIC microcontroller of type 18F4620.

The quad two input nand is used primarily as a buffer (to isolate the PIC chip from the 14CUX) but has a secondary function of acting as a 12v inverting interface. The raw road speed signal transducer outputs a 12v signal which passes through a potential divider before being passed into one nand gate and then to the PIC chip. Additionally the 14CUX serial port transmits a 12volt signal, but which is also inverted and so that signal has to be interfaced and complimented before being passed to the PIC (note that the 14CUX receive signal requires a non inverted +12volt signal, but in practice a 5volt signal drives it perfectly well).

The project complexity is hidden within the software programmed into the PIC chip. The key features of the PIC chip employed by this project are...

- 1. Large eprom space (64K bytes)
- 2. Large RAM space (by microcontroller standards 3968 bytes is huge)
- 3. E²PROM (1K bytes) for long persistent state
- 4. Built in I²C bus
- 5. Fully programmable Asynchronous UART with interrupt support
- 6. Timer counters with extensive interrupt support
- 7. Fast analog to digital convertion with interrupt support

The PIC chip is programmed using the Microchip ICD3 system employing the short flying lead (inside the processor unit) with a 6 pin RJ11 plug on the end. The software is written in C, and consumes just over 18KBytes of ROM and 142 bytes of RAM. E²PROM is used to hold persistent state data.

Processor Unit – Front Panel LED Wiring

The processor box has five LED's mounted on the front panel (one yellow, two amber, one green and one red). These are wired onto a small PCB and are wired without current limiting resistors and a small eight wire loom as shown below. The yellow and both amber LED's are connected to the processor. The yellow is used to show touch screen activity, and the two amber LEDs and can be used freely for debug by altering the software. The green LED illuminates when the engine cooling fans are switched on. The red LED illuminates when the 14CUX activates its EFi "check engine" warning light.



Figure 7 – Front Panel LED wiring in the processor unit

Processor Unit – LCD Wiring

The processor unit includes a BV4629-G colour 2.4" LCD module with integral touch screen. This 240 x 320 pixel colour screen (each pixel has 18 bits of colour depth) – has to be initialised before use (via a USB PC app) to load a new font in flash, and a set of ten images to use for the display of numeric MPH data. The LCD comes fitted with a controller board which also includes an I²C interface.



Figure 8 – Front Panel LCD wiring in the processor unit

Processor Unit – Schematic.

The processor unit schematic is shown on the following page.

Processor PCB Conn5

Description

This connector is actually a floating cable with a 6 pin RJ11 plug – and is the mechanism used by the ICD3 system to program the PIC 18F4620 processor chip.

Signal	Description and what it connects to
+5v	Yellow on a standard Microchip PIC break out cable
/MCLR	Blue on a standard Microchip PIC break out cable
PGM data	Red on a standard Microchip PIC break out cable
PGM Clock	Black on a standard Microchip PIC break out cable
Ground	Screen on a standard Microchip PIC break out cable
	Figure 0 Processor unit DCP ConnE (Microsphin programming 6 nin D111 cable)

Figure 9 – Processor unit PCB Conn5 (Microchip programming 6 pin RJ11 cable)



Where the colours shown relate to the Microchip cable part number AC162069 and are as follows...

RJ11 pin 1 (White) is not used

RJ11 pin 2 (black) is the PGM clock signal RJ11 pin 3 (red) is the PGM data signal RJ11 pin 4 (screen) is ground RJ11 pin 5 (Yellow) is +5V RJ11 pin 6 (Blue) is the /mclr signal to reset the cpu

Figure 10 - Cable layout of 6 pin RJ11 plug (in standard Microchip cable AC162069)

Processor unit DB15 Chassis Mounted Male Plug

Description

This male chassis mounted connector is on the back of the processor unit, and (via the long linking cable) connects the processor to the analog unit.

Pin	Description
Pin 1 and Pin 2	ignition switched +12v
Pin 13 and pin 14	Ground
Pin 15	Buffered Lambda left signal
Pin 12	Buffered Lambda right signal
Pin 3	14CUX serial port transmit signal
Pin 4	14CUX serial port receive signal
Pin 5	EFi Check light (the signal issued by the 14CUX when a "check engine" fault occurs. Note this is active low.
Pin 6	Engine electric cooling fans operating (this signal is active high and is asserted when the cooling thermostat senses an over temperature condition).
Pin 7	Buffered raw road speed transducer signal – as read from the transducer fitted in line with the speedometer cable
Pin 8	Road speed output signal. This is the 5v signal output from the processor unit to the analog interface unit – which uses a darlington pair to amplify the signal to swing between 12v and ground. That signal is in turn fed as an input to the 14CUX system in order to control when the 14CUX switches the vehicle to idle.
Pins 9, 10 and 11	Spare

Figure 11 – Processor unit rear chassis mounted 15 way male D type



Figure 12 – FIMS Processor logic schematic



Figure 13 – D-Type Connector Wiring Pin Numbering

Appendix B – TTS Plug Wiring

When a diagnostic unit is plugged into the 14CUX TTS loom plug, the following wiring layout is used.



Figure 14 – TTS wiring for a diagnostic unit